

# NC Express e<sup>3</sup>

Software version release: 22.1

20. April 2022

# New features in NC Express e<sup>3</sup> 22.1

Unfolding .....	3
Supported 3D formats and versions.....	3
The LASER machines .....	4
Laser corner destruct with separate X/Y size, LG+PSR .....	4
Preserve micro-joints on Laser commonline .....	5
Z-Axis travel setting .....	6
Reading “TulusParameters.xml” .....	7
The COMBI, Punch-Shear machines .....	9
Tooling reviewer .....	9
Punch destruct enhancements .....	9
The COMBI, Punch-Laser machines.....	10
Cut all outside last.....	10
Before punch-robot-sorting acceleration reduction.....	11
RALC improvements .....	12
Tolerate imprecise LP commonline nests.....	12
Other usability enhancements.....	13
New sheet and run reporting.....	13
Text marking in Autotool .....	15
Copy nest run from another machine .....	16
Show preview in part database .....	16
Windows support.....	17

# Unfolding

## Supported 3D formats and versions




- Autodesk Inventor (\*.ipt, \*.iam), up to 2022
- SolidWorks (\*.sldprt, \*.sldasm), up to 2022
- Solid Edge (\*.par, \*.psm, \*.asm), up to 2022
- Siemens JT (\*.jt), up to 10.7
- Siemens NX (\*.prt), up to 2000
- PTC Creo (\*.prt.x, \*.asm.x), up to 8.0
- Catia (\*.catproduct, \*.catpart), V4 (4.15 to 4.26) and V5 (R10 to R31), V6
- IGES (\*.igs, \*.iges), up to 5.3
- STEP (\*.stp, \*.step), AP203 (E1, E2), AP214 (up to E3), AP242 (E1, E2, BO XML), AP209
- Spatial Acis (\*.sat), up to 2021 1.0
- Parasolid (\*.x\_t, \*.x\_b), up to 34.0

# The LASER machines

## Laser corner destruct with separate X/Y size, LG+PSR

Laser corner destruct routine has been upgraded to allow the setting of minimum scrap size values separately in the X and Y directions.

Maximum scrap size values can be set on the **Destruct**-page of the **Autotool**-dialog:




The screenshot shows the 'Destruct' page of the 'Autotool' dialog box. It contains several settings for laser destructing:

- ☐ Laser destructing enabled
- Maximum hole size: 200
- Target scrap size: 40
- Minimum hole size: 2
- ☒ Laser cut narrow notches enabled
  - Maximum notch width: 10
  - Minimum notch depth: 5
- ☒ Complete notch destruct
  - Maximum scrap size X: 25
  - Maximum scrap size Y: 100


At the bottom are buttons for OK, Cancel, Apply, and Help.

The destruct pattern now depends on the notch orientation:




## Preserve micro-joints on Laser commonline

Micro-jointed parts can be automatically nested on the common-line if micro-joints are placed in the part corner notches.




## Z-Axis travel setting

The dialog *Machine parameters* provides a new section about *Z-axis travel* configuration for laser machines with Open-Tulus or Prima P20L/P30L control.




A default value is defined depending on the machine type.

When opening an existing nest, postprocessing automatically updates Z-axis positions (*Z end position*) within the Z-axis travel.



## Reading “TulusParameters.xml”

The dialog *Machine parameters* provide the button *Read Tulus parameters* for laser machines with Open-Tulus control.



It updates the NC Express data concerning the axis travel of X,Y,Z with the values of the real machine contained inside *TulusParameters.xml*. The procedure steps are:

- Press the *Read Tulus parameters*-button
- Browse *TulusParameters.xml* inside File System. The selected *TulusParameters.xml* will be copied inside the *WORK* folder of the current machine
- In case of different values, a confirmation pop up appears to update NC Express data.

The updated values inside the dialog are as follows:

Machine LG\_PLUS setup

General | Clamp data | Sorting | Clamp protection area | Misc | Laser config | Controller

☐ Punch head

Punch properties

	X	Y
Centerline:	0	0
Max. travel:	2000	1250
Min. travel:	0	0

☐ Tap head

Tap properties

	X	Y
Centerline:	0	0
Max. travel:	0	0
Min. travel:	0	0

☐ Shear head

Shear properties

	X	Y
Centerline:	0	0
Max. travel:	0	0
Min. travel:	0	0

☒ Profile head

Profile properties

	X	Y
Centerline:	0	0
Max. travel:	3048	1524
Min. travel:	-10	-10

☐ Scribe 1 head

Scribe 1 properties

	X	Y
Centerline:	0	0
Max. travel:	0	0
Min. travel:	0	0

☐ Scribe 2 head

Scribe 2 properties

	X	Y
Centerline:	0	0
Max. travel:	0	0
Min. travel:	0	0

Read Tulus parameters

OK Annulla

Machine LG\_PLUS setup

General | Clamp data | Sorting | Clamp protection area | Misc | Laser config | Controller

☒ LPM

☒ Sheet measurement

☒ Oil spray

☐ Bevel

☐ Clamps positioned along Y-axis

☐ Cell manager

☐ Retractable clamps

☐ Smart move

☐ Ping pong move

300 Max. head-down distance

☒ Optimize circle

Sheet support pattern...

☒ Lead-in technologies

☒ G41/G42 beam compensation

☐ Laser beam compensation per technology

☒ Overlap supported

Loading pins

Size: 50

Y offset: 0

Y offset: 0

X offset: 0

X offset: 0

Calibration table

Size: 300

Y offset: 750

Z axis travel

Min: 0

Max: 120

Read Tulus parameters


OK Annulla



# The COMBI, Punch-Shear machines


## Tooling reviewer

**Tooling - Reviewer** allows you to easily inspect each different internal contour in a part. If you choose to change the tool hits or laser on any contour, you can press the **Apply**-button to propagate it to all similar contours.



## Punch destruct enhancements


The **Autotool-Destruct-Any notch enabled** has various smaller enhancements in order to make more reliable punch destruct patterns.



# The COMBI, Punch-Laser machines


## Cut all outside last

As default, the internal laser tooling of parts is made part-by-part before sorting each part. The skeleton of a sheet starts to weaken as the processing of a sheet advances. If there is a lot of internal laser tooling, movements made to process the internal tooling can be problematic for the stability of a weakened skeleton. Now optimizer has a new setting, ***Do all outside last***, to do all the internal laser tooling of parts (within the same laser tooling package) before the external laser tooling. This setting helps to minimize processing movements after a skeleton starts to weaken when parts are released.




## Before punch-robot-sorting acceleration reduction

When a part is released by punching, the sheet may start to deform before releasing the part. This may cause inaccuracies to occur during nibbling. Now optimizer has a new setting, **Before robot sorting acceleration reduction**, to reduce acceleration before the punch-robot-sorting of a part. Acceleration can be linearly reduced on **Slowdown toolpath length** (percentage of part circumference), before a part is released. If **Sheet level acceleration reduction** is in use (End acceleration is less than 100%), smaller effective acceleration is used.



## RALC improvements


Robot assisted last cut (RALC, sorting type 14) is now better placed in **Autotool**. This concerns cases when laser cutting is clockwise or counter-clockwise, corners with rounding fillets or without.



## Tolerate imprecise LP commonline nests

Hand-made Laser-Punch commonline nest layouts can sometimes accidentally be imprecise, which makes creating a correct commonline cutting difficult or impossible. Software can now warn of such a situation, indicating the violating location.


Utilization: 92.7% #Sheets: 1



# Other usability enhancements

## New sheet and run reporting

64-bit NC Express has a new reporting functionality which uses new report templates. When new reporting is in use, there are two reporting buttons in the **Context**-category. **Sheet report** is to produce a report for an active nested sheet and **Run report** is to report information of all sheets in a nest. **NC Express Report Viewer** is launched to show the preview of a report. In the Report Viewer a user may choose the template to be used, export the report to different formats, print the report and so on.



Existing reporting settings in the **Settings-Options-Report**, remain the same. New reporting template files have the '.repx' extension. Template files are stored in folders '..\ncexpress\report\Sheet reports' and '..\ncexpress\report\Run reports'. It is possible to modify REPX-templates with **NC Express Report Designer** (included in NC Express e<sup>3</sup> installation). More information is available upon request.

Verifier   Unfolding   Database   **Settings**   Help   Context

Options... Layers...  
Misc


### Options

Tools and turret			PDM integration				PSBB Simulation		
General	DXF import	Autotool	Report	Order	Nest	Accept	External programs	Tulus integration	Stacking
<input checked="" type="checkbox"/> Generate report PDF file automatically after postprocessor.			Sheet report ▼						
<input type="checkbox"/> Print report automatically in nest explorer after accepting.									
<input checked="" type="checkbox"/> Open report automatically in nest explorer after accepting.			<input type="checkbox"/> Open report automatically after postprocessor.						
<input type="checkbox"/> Show report tool station name.			<input checked="" type="checkbox"/> Generate ".fms" file automatically after postprocessor.						
<input checked="" type="checkbox"/> Show report picture with tooling.			<input checked="" type="checkbox"/> Save last viewed report name.						
<input type="checkbox"/> Show report tool order as postprocessor.			<input checked="" type="checkbox"/> Draw tools to turrets and multi-tools						
<input type="checkbox"/> Show report tool only once.									
Sheet report: Report ▼			Run report: Run report ▼						

**Templates for new reporting are stored in folders '..\ncexpress\report\Sheet reports' and '..\ncexpress\report\Run reports'. Template selection works on available .repx template files.**

## Text marking in Autotool


Automatic part tooling can include text marking. The text position and content is defined on the **Text marking**-page in **Autotool**.



Text marking can include fixed text and part metadata. Text can be split into several lines by including the special character ‘\n’.

## Copy nest run from another machine


In multi-machine installations, it is now possible to copy a run folder to the active machine from any other machine. In the **New nest**-dialog click the **Copy selected run**-button and then select the source run folder.



After the source run folder has been selected the material code and/or thickness can be edited.

## Show preview in part database

Part preview is now shown in **Database-Parts**.





## Windows support

NC Express e<sup>3</sup> 22.1 supports Windows 7 and Server 2012 to 2019 up to the latest Windows 10 and Windows 11 version.

This version is available also as a 64-bit build. New installations are recommend to be made in 64-bit, whereas updates stay in 32-bit.

If you update an existing installation to 64-bit and it uses customized report templates, please be prepared to remake those report templates for new reporting. See chapter *New sheet and run reporting* for more information.